

Trouble shooting

SEV-05 Control Valve



General

I Valves are already adjusted and tested. Check electrical operation before changing valve settings. II Test that the correct solenoid is energized, by removing the nut and raising the solenoid slightly to feel pull III Make sure that flow guides (inserts) are correctly located after maintenance

Problem	Cause	Solution
It is not possible to adjust the solenoids to 2100 PWM.	<ol style="list-style-type: none"> 1. Location of the orifice for the solenoid needle is not correct. 2. Incorrect dimension of seat housing. 3. No spring. 4. Wrong solenoid needle (A or C) 	<ol style="list-style-type: none"> 1. Readjust needle (21.29 mm UP(A) – 33.11 mm DOWN (C)) 2. Change seat housing. 3. Insert spring. 4. Insert correct solenoid needle.
Adjustment screws of 1, 7 and 9 are too much out/in from the flange faces	<ol style="list-style-type: none"> 5. Flow guide (insert) size is too small/big – travel of the internal flow guide is too long/short ^(a). 	<ol style="list-style-type: none"> 5. If pressure difference (p min – p max.) is greater than 20bar, take next larger/smaller flow guide (insert) size.
Car is not moving in UP direction, and very slow in DOWN direction	<ol style="list-style-type: none"> 6. Error message on the SEV card; 'Sensor defect' 7. Signals for UP and DOWN are sent to the SEV card at the same time. 8. No input signals into the SEV card ^(c). 	<ol style="list-style-type: none"> 6. Correct the error by pressing ESCAPE button 7. Check the input signal and apply only in one direction at a time 8. Check the main controller signaling.
Car always over/under travels the stop	<ol style="list-style-type: none"> 9. Ex-center not correctly adjusted therefore, the actual leveling speed is much higher/lower than the target speed ^(b). 	<ol style="list-style-type: none"> 9. Adjust the Ex-center correctly (Refer to the SEV Handbook).
Sensor needs frequent adjustments (overflow) or it is difficult to adjust the sensor to its initial setting	<ol style="list-style-type: none"> 10. Defected sensor 11. Spring in the flow meter is broken 	<ol style="list-style-type: none"> 10. Change the sensor 11. Change the flow meter

UP Direction

Problem	Cause	Solution
Car does not start to travel or it is not possible to adjust by-pass pressure	<ol style="list-style-type: none"> 1. Solenoid 'A' not energized or insufficient power ^(c) 2. Incorrect spring pretension of solenoid 'A' 3. Solenoid tube 'A' has not been fastened enough 4. Dirt between needle and seat housing of Solenoid 'A' or one of them has been damaged. 5. Adjustment '1' has been opened too far, therefore pressure is too low (min. 5bar) or the by-pass flow guide (insert) is too big 6. Setting for pressure relive valve is too low 7. Pressure relief valve is leaking 8. Adjustment '2' closed too far (over compensation) 9. Solenoid 'A' energized but car doesn't move, when solenoid 'A' de-energized car starts to move rapidly 10. Pump turns in the wrong direction 11. Pump capacity is too small, or pump is worn out 12. Leakage at the pump-valve assembly. 	<ol style="list-style-type: none"> 1. Check the connector to solenoid 'A' 2. Start the car in leveling speed in UP direction then turn the adjustment c-clockwise on solenoid 'A' until car is travelling 3. Fasten Solenoid tube 'A' 4. Disassemble the solenoid 'A' clean all the parts, or replace damaged parts if needed 5. Turn adjustment '1' clockwise, or use a smaller by-pass flow guide (insert) 6. Close pressure relive valve completely, then apply 1 ½ turns c-clockwise out 7. Change the piston or the spring of the pressure relief valve 8. Turn out (c-clockwise) adjustment '2', if sealed exchange adjustment '2' completely 9. Wrong solenoid needle in solenoid 'A', replace with the correct one 10. If the pressure is not rising above 5 bar while adjusting adjustment '1' (turning clockwise) or through changing the by-pass valve insert to the next smaller size, please check 10), 11) or 12)
Car starts with a sudden pull	<ol style="list-style-type: none"> 13. Adjustment '1' has been turned in too far 14. Short delay valve is not closing 15. Under high pressure the Adjustment '2' cannot compensate enough, or it has been turned in too far. 16. For the pump, switching from "Star" to "Delta" kick is too late (i.e. the pump switches during acceleration). 17. O-ring (UO) at the by-pass valve is leaking. 18. Front O-ring (FO) at the check valve flange, (4F) is leaking 19. Extreme high friction in the rails or at the cylinder head. 	<ol style="list-style-type: none"> 13. Turn Adjustment '1' further out (c-clockwise). 14. Change Short delay valve flange 15. Replace adjustment '2' or turn it further out (c-clockwise). 16. Switching time of 0.2 to 0.3 s will be sufficient 17. Change O-ring (UO) at the by-pass valve 18. Change O-ring (FO) at the flange (4F) 19. This problem can't be solved through the SEV control block
Car does not decelerate properly from full speed	<ol style="list-style-type: none"> 20. O-ring (UO) at the by-pass valve is leaking 21. Setting for the deceleration time is too high 	<ol style="list-style-type: none"> 20. Change O-ring (UO) at the by-pass valve (SEV 1½" + 2": 39,3x2,6 ; SEV 2½": 58,0x3,0) 21. Use lower setting for the deceleration time
Car decelerates, but over travels the stop or has a sudden stop	<ol style="list-style-type: none"> 22. Deceleration signal is set too late 23. Setting for deceleration time is too high 24. Dirt in Plug '5' 25. Setting for leveling speed too high 26. The adjustment '1' is not set properly therefore, by-pass valve cannot open wide enough. 27. The car stops suddenly and too hard, because the soft stop is set too soft 28. Because of too low static pressure, dynamic pressure drops too far ^(d). 	<ol style="list-style-type: none"> 22. Move the switch to the right position 23. Lower setting for deceleration time (Standard: 2,5s) 24. Clean Plug '5' 25. Lower the setting for leveling speed 26. Turn adjustment '1' two turns (c-clockwise) out and check the effect. 27. Increase setting for soft stop (Standard setting: 60%) 28. Use next lager insert -> or/and Increase pressure / weight -> or/and Reduce friction between car and rails -> or/and Decrease up speed -> or/and Adjust the deceleration time to a higher setting and if necessary, change the position of the deceleration switch
Vibration during the entire travel	<ol style="list-style-type: none"> 29. Location of the orifice for the solenoid needle is incorrect (distance is too long). 30. Flow guide (insert) size too big ^(a) 31. Gain setting too high 	<ol style="list-style-type: none"> 29. Place a 1.4mm drill tip in the needle orifice and adjust the distance between drill tip and the solenoid core to 21.29mm or a tiny bit less -> 21,23mm 30. In case the gain is < 7 use the next smaller flow guide(insert) 31. Lower gain setting (should not be smaller than 5)

Trouble shooting SEV-05 Control Valve



Vibration while travelling through some sections.	32. Control parameters are not optimal	32. Lower gain setting or change setting of the slope variable P- and D- (call for service)
Valve reacts too slow (Waves at the travel graph)	33. Location of the orifice for the solenoid needle is incorrect (distance is too small). 34. Flow guide (insert) size is too small ^(a) 35. Gain setting is too small	33. Place a 1.4mm drill tip in the needle orifice and adjust the distance between drill tip and the solenoid core to 21.29mm or a tiny bit longer->21.34mm 34. In case the gain is > 11 use the next bigger flow guide(insert) 35. Increase gain setting

DOWN Direction

Problem	Cause	Solution
No down travel	1. Solenoid 'D' is not energized or insufficient power ^(c) 2. O-ring at the down valve (UO) is leaking	1. See Note II on the first page 2. Change O-ring (UO) at the down valve (SEV 1½" + 2": 39.3x2.6 ; SEV 2½": 58.0x3.0)
Cannot reach full speed	3. Adjustment '7' is not opened enough 4. No input signal to the SEV card for full down speed ^(c)	3. Open adjustment '7' (turn out '7' c-clockwise) 4. Check input signal at the SEV card (for full down speed the two small red LED should be illuminated)
Full down speed, but no leveling speed	5. Adjustment '9' not opened enough or/and ex-center adjustment is not correct ^(b) 6. Broken spring (9F) on the adjustment '9' .	5. Adjust the No 9 approximately to the flange level or/and correct the ex-center 6. Check the spring and if needed change the spring.
Car does not decelerate from full speed and over travels the stop	7. Leveling speed '9' is set too high 8. The solenoid 'C' is not closing completely 9. The first O-ring (FO) of the flange (7F) is leaking	7. Turn in adjustment '9' (clockwise) to adjust leveling speed (Standard: 0.03m/s); There are two ways: 1) Open manual lowering valve or 2) Energize only solenoid D. 8. Clean Solenoid 'C', or change needle and seat housing 9. Change O-ring (FO) at the down flange (EV 1½" + 2" 47.0x2.5; EV 2½" 58.0x3.0)
Leakage, Car is sinking	10. Solenoid tube 'D' has not been fastened enough 11. Leakage at DN, DS, XO, VO, WO, FO, or HO 12. Short delay valve is not closing 13. Leakage of a hand pump or other valves if attached 14. Contraction through cooling down of the hot oil, especially oil temperature above 40°C	10. Fasten Solenoid tube 'D' 11. Check the components and if needed replace them in the listed sequence 12. Replace flange 'E' 13. Detach return pipe and check for leakage; if needed change hand pump or other attached components. 14. Install oil cooler if needed
Valve reacts too slow (Waves at the travel graph)	15. Location of the orifice for the solenoid needle is incorrect (distance is too small). 16. Inside dimension of the seat housing are not correct. 17. Dimension of the fix drilled hole Ø 0.7 mm of adjustment '8' is too small 18. Size of the flow guide (insert) is too small ^(a) 19. Gain is too small	15. Place a 1.4mm drill tip in the needle orifice and adjust the distance between drill tip and the solenoid core to 33.11mm or a tiny bit longer-> 33.16mm 16. Change seat housing 17. Replace adjustment '8' 18. In case the gain is > 11 use the next bigger flow guide 19. Increase gain setting
Vibration during the entire travel	20. Location of the orifice for the solenoid needle is incorrect (distance is too long). 21. Flow guide (insert) size too big ^(a) 22. Gain setting too high	20. Place a 1.4mm drill tip in the needle orifice and adjust the distance between drill tip and the solenoid core to 33.11mm or a tiny bit smaller-> 33.06mm 21. In case the gain is < 6 use the next smaller flow guide 22. Decrease gain setting (should not be smaller than 5)
Opening manual lowering valve under high pressure, but car is not lowering	23. The nozzle hole in down leveling valve '9' is too small or is not there. 24. 'KS' adjustment is set too high	23. Replace Down leveling valve 24. Readjust 'KS'
Lowering speed is too high when opening manual lowering	26. Solenoid tube 'C' not fastened 27. Adjustment '9' is set too high	26. Fasten Solenoid tube 'C' 27. Readjust '9'

Additions:

- (a) i- When the flow guide (insert) size is too small, travel of the flow guide (insert) is longer. At low pressures, oil pressure behind the by-pass valve cannot build up fast enough therefore, waves during the travel may occur.
ii- When the flow guide (insert) size is too big, travel of the flow guide (insert) is shorter. At high pressures, flow is more difficult to control therefore, vibration during the travel may occur.
- (b) Ex-center is factory adjusted. Unless its adjustment is spoiled, the adjustment is not necessary. When the leveling speed is too high/low, the car over/under travels. Even though the leveling speed is lowered/increased, the actual leveling speed could still be higher/lower than the setting. This situation occurs due to incorrect ex-center adjustment (Refer to the SEV Handbook).
- (c) Small Led's on the card (green for up direction, red for down direction and yellow for inspection) show input signals, big Led's (green for up direction, red for down direction) show output signals to the solenoids. If they are not illuminated during the operation then the card is not receiving and outputting signals.
- (d) Pressure behind the by-pass flow guide (insert) cannot build-up quick enough therefore; reaction of the by-pass flow guide (insert) is slowly. This situation occurs at extremely low working pressures (below 12bar). One of the remedies is to use a bigger size by-pass flow guide (insert).
- (e) When the gain value is changed, fine-tuning of the solenoid may be re-done.
- (f) A factory-adjusted valve may only require fine-tuning for the solenoids of maximum ±45°. However, if the valve input values have been changed then one may require more degrees of turns than that.